



Wireless pushbutton with intermediate frame and rocker (without frame)



Wireless pushbutton with intermediate frame and double rocker (without frame)

FT4B-

Wireless pushbutton Niko Pure / Intense / Original

Wireless 4-way pushbutton 55x55 mm Pure / Intense / Original. Generates the power for wireless telegrams itself when the button is pressed, therefore there is no connecting wire and no standby loss. With rocker and double rocker.

FT4B-cr	Wireless 4-way pushbutton 55x55 mm Pure / Intense / Original, Niko cream	EAN 4010312312995	44,50 €/pc.
FT4B-na	Wireless 4-way pushbutton 55x55 mm Pure / Intense / Original, Nikoanthracite	EAN 4010312314180	44,50 €/pc.
FT4B-nw	Wireless 4-way pushbutton 55x55 mm Pure / Intense / Original, Nikowhite	EAN 4010312312902	44,50 €/pc.