


## FTD14



### Telegram duplicator for the Eltako RS485 bus with exchangeable antenna. Only 0.5 watt standby loss.

Modular device for DIN-EN 60715 TH35 rail mounting. 1 module = 18mm wide, 58mm deep.

**Connection to the Eltako-RS485 bus. Bus cross wiring and power supply with jumper. Operation in conjunction with FAM14 or FTS14KS.**

The telegrams of taught-in IDs are duplicated and directly sent into the Eltako wireless network with a new output ID. These wireless telegrams can be specifically taught-in in decentralized actuators.

**A total of 120 memory locations are available.**

**The upper rotary switch** is used to selectively transmitting a wireless telegram. In normal operation, it is set to RUN.


**The bottom rotary switch** is used for teaching-in and deleting IDs. In normal operation, it is set to RUN.

**The red LED** below the upper rotary switch performs during the teaching-in process.

**The green LED** below the lower rotary switch lights up briefly when a wireless telegram is transmitted.

The enclosed small antenna can be replaced with a wireless antenna FA250 with magnetic base and cable.

### Function rotary switches



Standard setting ex works.

Further settings can be made and actuators configured using the PC Tool PCT14.

Housing for operating instructions GBA14 page 1-42.